


RUNNER II R1 A/B RUNNER II R1 C/D RUNNER II R2 A/B RUNNER II R2 C/D





WWW.AGURI.EU





LIT Pritvirtinimo instrukcijos
PL Instrukcja montażu
CZ Návod na montáž
SK Návod na montáž
SLO Navodila za pritrjevanje
HR Uputa za sastavljanje
HU A felszerelés módja
GR Οδηγίες συναρμολόγησης
UA Інструкція з монтажу
BY Інструкцыя па мантажы
RO Instrucțiuni de montare
TK Uydurma talimat
N Monteringsveiledning

I Istruzioni per il montaggio
GB Fitting instructions
F Instructions de montage
D Montageanleitung
E Instrucciones de montaje
NL Montage-instructies
DK Monteringsinstruktion
FIN Asennusohje
S Monteringsanvisning
RU Инструкция по установке
PT Instruções de Montagem
EST Paigaldusjuhend
LAT Stiprināšanas instrukcija



RUNNER A/B





CHECK
APPLICATION

A

B



RUNNER C/D





CHECK
APPLICATION


C

D







1 - 2 - 3 - 4




1 - 2 - 3 - 4




1 - 2 - 3 - 4









1 - 2 - 3 - 4



CHECK





OPTIONAL ACCESSORIES

