




50485












ACTIVE E-BIKE











LIT Pritvirtinimo instrukcijos
PL Instrukcja montażu
CZ Návod na montáž
SK Návod na montáž
SLO Navodila za pritrjevanje
HR Uputa za sastavljanje
HU A felszerelés módja
GR Οδηγίες συναρμολόγησης
UA Інструкція з монтажу
BY Інструкцыя па мантажы
RO Instrucțiuni de montare
TK Uydurma talimat
N Monteringsveiledning


I Istruzioni per il montaggio
GB Fitting instructions
F Instructions de montage
D Montageanleitung
E Instrucciones de montaje
NL Montage-instructies
DK Monteringsinstruktion
FIN Asennusohje
S Monteringsanvisning
RU Инструкция по установке
PT Instruções de Montagem
EST Paigaldusjuhend
LAT Stiprināšanas instrukcija







	50485	
 KG		
	19,5 KG	
50 KG	-19,5 KG	30,5 KG
60 KG	-19,5 KG	40,5 KG
70 KG	-19,5 KG	50,5 KG
80 KG	-19,5 KG	60,5 KG









13 PIN



FOR LOAD







OK



NO!




OK











NO



OK



min 20 mm
max 80 mm







LIFT AND TOW

ACCESSORIES




50532



**50484
LOADING RAMP**




40070



13 PIN / 7 PIN

50072



50538

30 x 30 cm