

MARATHON

SILVER **50422**




BLACK **50423**

WWW.AGURI.EU









LIT Pritvirtinimo instrukcijos
 PL Instrukcja montażu
 CZ Návod na montáž
 SK Návod na montáž
 SLO Navodila za pritrjevanje
 HR Uputa za sastavljanje
 HU A felszerelés módja
 GR Οδηγίες συναρμολόγησης
 UA Інструкція з монтажу
 BY Інструкцыя па мантажы
 RO Instrucțiuni de montare
 TK Uydurma talimat
 N Monteringsveiledning

I Istruzioni per il montaggio
 GB Fitting instructions
 F Instructions de montage
 D Montageanleitung
 E Instrucciones de montaje
 NL Montage-instructies
 DK Monteringsinstruktion
 FIN Asennusohje
 S Monteringsanvisning
 RU Инструкция по установке
 PT Instruções de Montagem
 EST Paigaldusjuhend
 LAT Stiprināšanas instrukcija






INSTALLATION

FRONT



REAR







ADAPTERS 50976






	<p>Adapter A</p>  2 pc. <p>Adapter D</p>  2 pc.	<p>9x100 (A+D+D+A)</p>
	<p>Adapter C Adapter D</p>  1 pc.  2 pc. <p>Adapter B Adapter A</p>  1 pc.  1 pc.	<p>12x100 (B+D+D+C+A)</p>
	<p>Adapter C</p>  2pc. <p>Adapter D</p>  2 pc.	<p>15x100 (C+D+D+C)</p>



ADAPTERS 50976

	<p>Adapter C</p>  2 pc. <p>Adapter BOOST</p>  2 pc.	<p>BOOST (C+BOOST+BOOST+C)</p>
	<p>Adapter FOX</p>  1 pc. <p>Adapter C</p>  2pc. <p>Adapter D</p>  2 pc.	<p>FOX 100 (FOX+D+D+C)</p>
	<p>Adapter C</p>  1 pc. <p>Adapter BOOST</p>  2 pc. <p>Adapter FOX</p>  1 pc.	<p>FOX 110 (FOX+BOOST+ +BOOST+C)</p>







WWW.AGURI.EU